


Actual product size

H74.5 x W175 x D100cm (TABLE) H88 x W62 x D65cm (CHAIR)



Need Help?

With: Assembly Instructions Missing or damaged parts

IMPORTANT-RETAIN FOR FUTURE REFERENCE

CALL: 0333 777 8999

nex

TARANTO DINING SET 118163 Assembly instructions

BEFORE YOU START

Warnings

Important: Retain these instructions for future reference.

Unwrap all packaging materials and place the components on unit into position. top of the carton box or on a clean floor to prevent it from scratching.

This product should only be used on firm, level ground. Keep small parts out of reach of children.

Do's

We suggest you spend a short time reading through this leaflet before you start.

When you are ready to start, make sure that you have the right tools, plenty of space and a clean, dry area for assembly.

Check the pack and make sure you have all the parts listed.

During assembly children should be kept away from the product due to possible risk of injury.

Tools included.

Due to the size of this product we recommend that it is assembled in the room intended for use.

Ensure that this product is fully assembled as illustrated before use.

Make sure the legs remain in contact with the ground.

Check all screws or bolts are tightened and inspect regularly.

To clean wipe with a sponge and warm soapy water. Do not use solvent based cleaners or detergents as they can bleach or damage the product.

Please put a cushion to avoid any potential loose.

Don'ts

Number of people required to assemble


Two persons to assemble the unit and two persons to lift the

Time to assemble



90 minutes

Tools required



Missing parts

If you are missing any fixtures and fittings for your product please contact our customer service team on 0333 777 8999 and they will be happy to arrange for a replacement to be sent to you free of charge.

Home service technicians

If you have a fault with your product please contact our customer service team on 0333 777 8999. If you have had the product for 28 days or less you may be offered a replacement, refund or for a fully trained home service technician to visit your home to assess the fault and repair the product where possible. If you have had the product for more than 28 days we will send an independant home service technician to review and repair the product where possible and recommend further action.

Don'ts	
Do not use power tools to construct this product.	You can write to us at Next Retail Ltd.
Do not tighten screws until fully assembled.	Desford Road.
Do not overtighten screws or bolts.	Leicester.
Do not sit or stand on the product.	LE194AT
Do not use this product if parts are missing, damaged or worn.	To view our full furniture range please visit www.next.uk
Never use scourers, abrasives or chemical cleaners.	

Do not leave cushions outdoors when not in use.

NEXT 11816 Assert

CUSTOMER HELPLINE


If you have any problem with this product or require any replacement fittings please contact customer services 0333 777 8999

Components supplied


Ref	Dimensions	Visual	Qty
1	173x98cm		1
2	175x100cm	H	1
3	10x72cm		2
4	10x72cm		2
5	62x65cm		6
6	10x43cm	1	24
7	49x49cm	\diamond	6


Fixtures and fittings supplied (actual size)

		10	20	30	40	50	60	70	
Ref	Dimensions	Visual			Qty	Spare Fitting			
А	ø 1 3 x 5 m m					112	14		
В	ø 6 x 2 0 m m)		112	14		
С	ø12x1.0mm					112	14		













GETTING TO KNOW YOUR PRODUCT





2

