

next


OSBOURNE DRESSING TABLE

383598

Assembly instructions

Actual product size

H83xW135xD44cm



Need Help?

With: Assembly instructions
Missing or damaged parts

CALL:0333 777 8999

IMPORTANT- RETAIN FOR FUTURE REFERENCE

BEFORE YOU START

Warnings

We suggest you retain these instructions for future reference. Keep fittings out of children's reach and keep children well away from construction area.

This product should only be used on firm, level ground.

Please periodically check all fittings and re-tighten as necessary.

Please do not sit or stand on your table.

Avoid exposing the furniture to excessive heat or direct sunlight as this can cause cracking of the wood and deterioration of the colour.

Unwrap all packaging materials and place the components on top of the carton box or on a clean floor to protect it from damage.

Do's

We suggest you spend a short time reading through this leaflet before you start.

When you are ready to start, make sure that you have the right tools and plenty of space.

Unwrap all packaging materials and place the components on a clean surface to protect it from damage.

We recommend that the packaging is used to protect the surfaces during assembly.

Carefully check that you have all the parts before beginning assembly.

Due to the size of the product we recommend that it is assembled in the room intended for use.

Ensure the product is fully assembled as illustrated and all fixings fully tightened before use. Check fixings regularly to ensure they remain tight.

Wood will mellow and change colour over time; we recommend that ornaments and items placed on the surface are moved regularly for the first few months to prevent uneven mellowing.

When cleaning glass panels use a damp cloth with washing up liquid or soft soap if necessary. Do not use washing powders or any other substances containing abrasives since these substances can scratch the glass.

Don'ts

When moving furniture never drag the pieces across the floor, as this will cause damage to the joints. Apply adhesive substrates for example, sticky tape to the product.

Do not use silicone based furniture polish. Silicone in furniture polishes can break down the lacquer finish.

Don'ts(Continue)

If the glass is chipped or broken, stop using the product and consult NEXT.

Do not place very hot or very cold items on the glass surface, unless adequately thick table mats or coasters are used to prevent such items from coming into contact with the glass.

Do not use glass as a chopping surface. Do not strike the glass with hard or pointed items.

Number of people required to assemble

2 persons to assembly

Time to Assemble



30 minutes

Missing parts

If you are missing any fixtures and fittings for your product please contact our customer service team on 0333 777 8999 and they will be happy to arrange for a replacement to be sent to you free of charge.

Home service technicians

If you have a fault with your product please contact our customer service team on 0333 777 8999. If you have had the product for 28 days or less you may be offered a replacement, refund or for a fully trained home service technician to visit your home to assess the fault and repair the product where possible. If you have had the product for more than 28 days we will send an independent home service technician to review and repair the product where possible and recommend further action.


You can write to us at

Home Customer services
Next Retail Ltd,
Desford Road
Leicester
LE19 4AT

To view our full furniture range please visit
www.next.co.uk

PRODUCT SUPPLIED WITH WALL FIXING STRAPS

GETTING TO KNOW YOUR PRODUCT



Component supplied





Ref	Dimensions	visual	Qty
1	135x44x17.5cm		1
2	40x44x83cm		1
3	40x44x83cm		1

Fixture and Fittings supplied (not to scale)

Ref	Dimensions	visual	Qty
A	220x20mm		2

Fixture and Fittings supplied(actual size)

mm 10 20 30 40 50 60 70 80 90 100

REF	DIMENSIONS	QTY	Spare Part *	
B	65X25MM	1	0	
C	12X37.5MM	12	2	
D	13X2MM	12	2	
E	16X1MM	12	2	
F	7X17MM	2	1	
G	13X1MM	4	1	

* Just to let you know we have included a small quantity of fixings in case of mishap, so don't worry if you've got a few left when you've finished.


next

OSBOURNE DRESSING TABLE


383598

Assembly instructions

1



2



65X25MM Bx1	12X31MM Cx12	13X2MM Dx12	16X1MM Ex12


next

OSBOURNE DRESSING TABLE

383598

Assembly instructions

3




Produced in China for Next Retail Ltd.

383598-2015-V1

4

We recommend the use of the wall strap provided for safety reasons. Wall fixing are not included please source suitable fixing for your wall type. If in doubt, please consult a qualified tradesperson. **WARNING:** Always ensure the wall to be drilled is free from hidden electrical wires, water and gas pipes.



7x17MM F X 2 	13x1MM G X 4 	220x20MM A X 2 
--	--	--

next

OSBOURNE DRESSING TABLE

383598

Assembly instructions

Actual product size

H83xW135xD44cm

