

next


SHOREDITCH WOOD BED-DOUBLE

654344

Assembly instructions

Actual product size

H201.7 x W146 x D115cm



IMPORTANT - RETAIN FOR FUTURE REFERENCE

BEFORE YOU START

Warnings

Important: Retain these instructions for future reference.

WARNING Do not leave your child unattended-your child's safety is your responsibility.

WARNING Do not use the changer or dresser if any part is broken, torn or missing.

WARNING There are many small components used in the construction of this changer or dresser, these items should be kept out of reach of young children whilst assembling the unit .

Avoid exposing the furniture to excessive heat or direct sunlight as this can cause deterioration of the colour.

WARNING Never leave babies unattended.

Do's

When you are ready to start, make sure that you have the right tools and plenty of space.

Due to the size of the product we recommend that it is assembled in the room intended for use.

Take care that no screws are loose, because a child could trap parts of the body or clothing, which could pose a risk of strangulation.

Unwrap all packaging materials and place the components on a clean surface to protect it from damage, We recommend that the packaging is used to protect the surfaces during assembly.

Carefully check that you have all the parts before beginning assembly.

Please periodically check all fittings and re-tighten as necessary. Please do not drag or pull your furniture.

Wipe occasionally with a soft cloth slightly dampened with water. Then buff with a dry clean soft cloth.

Wipe occasionally with a soft cloth slightly dampened with water. Then buff with a dry clean soft cloth.

We recommend a changing pad no more than 3cm in thickness.

Place your changer or dresser on a stable surface.

Don'ts

Never allow any kind of liquid to remain on your furniture. Absorption can cause wood to warp or finishes to de-laminate.


Do not place your changer or dresser in the close proximity of an open fire and the sources of heat, such as radiators, electric or gas fires.

Do not place your changer in the close proximity of windows.

Number of people required to assemble

Two people are required to assemble this item


Time to assemble




Tips

Look out for the symbol throughout this manual. Wherever you see it we will have a handy tip to help you with the assembly of your product.

Tools required



not supplied



not supplied

Missing parts

If you are missing any fixtures and fittings for your product. Please contact our customer service team on **0333 777 8999** and they will be happy to arrange for a replacement to be sent to you free of charge

Home service technicians

If you have a fault with your product. Please contact our customer service team on **0333 777 8999**. If you have had the product for 28 days or less you may be offered a replacement, **refund** or for a fully trained home service technician to visit your home to assess the fault and repair the product where possible. If you have had the **product** for more than 28 days we will send an independent home service technician **to** review and repair the product where possible and recommend further action.


You can write to us at

Home customer Services

Next Retail Ltd.
Desford Road,
Leicester,
LE 19 4AT

To view our full furniture range please visit www.next.co.uk







GETTING TO KNOW YOUR PRODUCT




















CUSTOMER HELPLINE

If you have any problem with this product or require any replacement fittings please contact customer services **0333 777 8999**

Components supplied

Ref	Dimensions	Visual	Qty
1	146 x 115cm		1
2	146 x 75cm		1
3	192 x 16cm		2
4	33.2x 6.8cm		2
5	193.3x 6.8cm		1
6	67.8 x 6cm		32

Fixtures and fittings supplied

Ref	Dimensions	Visual	Qty
A	D10×40mm		8
B	Φ3.5×15mm		20
C	Φ6×Φ20mm		8
D	Φ7×50mm		4
E	60×23mm		1
F	Φ6×40mm		4
G	M6		4
H	L=1852mm		2
I	82×22mm		1
J	61×25mm		1
K	Φ8×70mm		8
L	70×44×40mm		2
M	23×23×30mm		4
N	31×15×8mm		8
O	M8		8
P	66×30×28mm		16
Q	66×58×28mm		32


next

SHOREDITCH WOOD BED-DOUBLE

654344

Assembly instructions

1



K x8

D8x70mm

L x2


70x44x40mm

B x4

Φ3.5x15mm



2



A x8

D10x40mm




next

SHOREDITCH WOOD BED-DOUBLE

654344

Assembly instructions

3



Bx16 $\Phi 3.5 \times 15\text{mm}$



Dx4

$\Phi 7 \times 50\text{mm}$




Mx4

23x23x20mm



4




next

SHOREDITCH WOOD BED-DOUBLE

654344

Assembly instructions

5



Nx8


31x15x8mm

Ox8

M8



6



Gx4

M6

Cx8

Φ6xΦ20mm

Fx4

Φ6x40mm



66×58×28mm



X 2

$L=1852\text{mm}$




next

SHOREDITCH WOOD BED-DOUBLE

654344

Assembly instructions

9



Q x32 66x30x28mm



10

