

686282 Assembly instructions

Actual product size H183 x W34 x D25cm



With: Assembly instructions Missing or damaged parts

CALL: 0333 777 8999

IMPORTANT – RETAIN FOR FUTURE REFERENCE



686282

Assembly instructions

BEFORE YOU START

Warnings

We suggest you retain these instructions for future reference.

Keep fittings out of children's reach and keep children well away from the construction area.

This product should only be used on firm, level ground.

Please periodically check all fittings and re-tighten as necessary.

Please do not sit or stand on your furniture.

Avoid exposing the furniture to excessive heat or direct sunlight as this can cause deterioration of the colour.

Unwrap all packaging materials and place the components on top of the carton box or on a clean floor to protect it from damage.

Do's

We suggest you spend a short time reading through this leaflet before you start.

When you are ready to start, make sure that you have the right tools and plenty of space.

Unwrap all packaging materials and place the components on a clean surface to protect it from damage.

We recommend that the packaging is used to protect the surfaces during assembly.

Carefully check that you have all the parts before beginning assembly

Due to the size of the product we recommend that it is assembled in the room intended for use.

Ensure the product is fully assembled as illustrated and all fixings are fully tightened before use.

Wipe occasionally with a soft cloth slightly dampened with water. Then buff with a dry clean soft cloth.

Wood will mellow and change colour over time, we recommend that ornaments and items placed on the surface are moved regularly for the first few months to prevent uneven mellowing.

When cleaning mirror panels use a damp cloth with washing up liquid or soft soap if necessary. Do not use washing powders or any other substances containing abrasives since these substances can scratch the mirror.

You can write to us at

Home Customer Services Next Retail Ltd, Desford Road. Leicester. LE19 4AT

PRODUCT SUPPLIED WITH WALL FIXING STRAPS


Number of people required to assemble

Two persons are required to assemble this item.

Time to assemble



Tools required





Don'ts

Do not drag or pull your furniture.

Do not use silicone based furniture polish. Silicone in furniture polishes can break down the finish.

Never allow any kind of liquid to remain on your furniture.

Absorption can cause wood to warp or finishes to de-laminate.

Do not place hot items (e.g. hot drinks) directly on to the wood surface. Please make sure you use a placement or coaster.

Do not use mirror as a chopping surface. Do not strike the mirror with hard or pointed items

Missing parts

If you are missing any fixtures and fittings for your product please contact our customer service team on 0333 777 8999 and they will be happy to arrange for a replacement to be sent to you free of charge.


Home service technicians

If you have a fault with your product please contact our customer service team on 0333 777 8999. If you have had the product for 28 days or less you may be offered a replacement, refund or for a fully trained home service technician to visit your home to assess the fault and repair the product where possible. If you have had the product for more than 28 days we will send an independant home service technician to review and repair the product where possible and recommend further action.

To View our full furniture range please visit www.next.co.uk

Assembly instructions

next



Components supplied. Please use this guide if you require replacement parts.

Ref	Dimensions	Visual	Qty	Ctn	Ref	Dimensions	
1	25 x 34cm		1	1	8	3 x 26cm	
					9	3 x 26cm	
2	24 x 181cm		1	1	10	30 x 171cm	
3	24 x 181cm	· · · · · · · · · · · · · · · · · · ·	1	1			
4	22 x 26cm	x 26cm	1		11	26 x 57cm	
				1	12	4 x 26cm	
5	22 x 26cm	• • • •	1	1			
6	23 x 25cm		3	1			
7	19 x 26cm		1	1			

Ref	Dimensions	Visual	Qty	Ctn
8	3 x 26cm	•	1	1
9	3 x 26cm	+	1	1
10	30 x 171cm		1	1
11	26 x 57cm		1	1
12	4 x 26cm	⊕ * ⊕	1	1

686282

next

Assembly instructions

Fivti	ures and fittin	ae	
supp	olied (actual s	ize)	mm 10 20 30 40 50 60 70 80 90 100 110 120 130
Ref AA	Dimensions 8 x 30mm	Qty 16	
AB	6 x 41mm	12	
AC	6 x 44mm	6	
AI	15 x 12mm	18	
AG	3.5 x 14mm	12	
AK	3 x 16mm	26	
AM	3.5 x 25mm	1	
AP	5 x 16mm	4	


Fixtures and fittings supplied(not to scale)

Ref	Dimensions	Visual	Qty
BA			12
BD			2
BE	26mm		2

686282

nex

Assembly instructions




Produced in China for Next Retail Ltd. 686282-2014-V1


686282


nex

Assembly instructions



nex






Produced in China for Next Retail Ltd. 686282-2014-V1


Assembly instructions

next



686282 Assembly instructions


next




686282-2014-V1

Assembly instructions

next




PURE SPA TALLBOY next 686282 Assembly instructions



PURE SPA TALLBOY next 686282


Assembly instructions



Produced in China for Next Retail Ltd. 686282-2014-V1


nex 686282

PURE SPA TALLBOY



686282 Assembly instructions


next



Assembly instructions

13

N.B. Wall fixings are not included please source suitable fixings for your wall type. If in doubt, please consult a qualified tradesperson. WARNING: Always ensure the wall to be drilled is free from hidden electrical wires, water and gas pipes.




PURE SPA TALLBOY next 686282 Assembly instructions





Hinge adjustment: Once the product is in the required position, the doors may need to be aligned as follows:

Laterally (side to side)



Front-to-back







686282



H183 x W34 x D25cm

