

Need Help?

With: Assembly instructions Missing or damaged parts

CALL: 0333 777 8999

IMPORTANT - RETAIN FOR FUTURE REFERENCE

BEFORE YOU START

Warnings

We suggest you retain these instructions for future reference.

Keep fittings out of children's reach and keep children well away from the construction area.

This product should only be used on firm, level ground.

Please periodically check all fittings and re-tighten as necessary.

Please do not sit or stand on your furniture.

Avoid exposing the furniture to excessive heat or direct sunlight as this can cause deterioration of the colour.

Do's

We suggest you spend a short time reading through this leaflet before you start.

When you are ready to start, make sure that you have the right tools and plenty of space.

Unwrap all packaging materials and place the components on a clean surface to protect them from damage.

We recommend that the packaging is used to protect the surfaces during assembly.

Carefully check that you have all the parts before beginning assembly.

Due to the size of the product we recommend that it is assembled in the room intended for use.

Ensure the product is fully assembled as illustrated and all fixings are fully tightened before use.

Wipe occasionally with a soft cloth slightly dampened with water. Then buff with a dry clean soft cloth.

Wood will mellow and change colour over time, we recommend that ornaments and items placed on the surface are moved regularly for the first few months to prevent uneven mellowing.

Don'ts

Do not drag or pull your furniture.

Do not use silicone based furniture polish. Silicone in furniture polishes can break down the finish.

Never allow any kind of liquid to remain on your furniture.

Absorption can cause wood to warp or finishes to de-laminate.

Do not place hot items (e.g. hot drinks) directly on to the wood surface. Please make sure you use a placement or coaster


Number of people required to assemble

Two persons are required to assemble this item.

Time to assemble



Tools required



Missing parts

If you are missing any fixtures and fittings for your product please contact our customer service team on 0333 777 8999 and they will be happy to arrange for a replacement to be sent to you free of charge.

Home service technicians

If you have a fault with your product please contact our customer service team on 0333 777 8999. If you have had the product for 28 days or less you may be offered a replacement, refund or for a fully trained home service technician to visit your home to assess the fault and repair the product where possible. If you have had the product for more than 28 days we will send an independant home service technician to review and repair the product where possible and recommend further action.


You can write to us at

Home Customer Services Next Retail Ltd, Desford Road, Leicester, I F19 4AT

To View our full furniture range please visit www.next.co.uk

next Modular Slide Door Oak Mirror Small 690510 Assembly instructions

GETTING TO KNOW YOUR PRODUCT





Components supplied. Please use this guide if you require replacement parts.

Ref	Dimensions	Visual	Qty	Ctn
M70-615	208 x 76cm		1	1
M70-616	208 x 76cm		1	1

NODULAR SLIDE DOOR OAK MIRROR SMALL

Assembly instructions





Fixtures and fittings supplied (not to scale)

Ref	Dimensions	Visual	Qty
H1	N/A		2
Ref	Dimensions	Visual	Qty
H2	N/A	(2) <u>19</u>	2
Ref	Dimensions	Visual	Qty
НЗ	N/A		2
Ref	Dimensions	Visual	Qty
H4	N/A		2
Ref	Dimensions	Visual	Qty
H5	N/A	L R	1
Ref	Dimensions	Visual	Qty
H6	N/A		1

Ref	Dimensions	Visual	Qty
H7	N/A		2
Ref	Dimensions	Visual	Qty
L1	N/A		1
Ref	Dimensions	Visual	Qty
L2	N/A		1
Ref	Dimensions	Visual	Qty
L3	N/A		2
Ref	Dimensions	Visual	Qty
L4	N/A		2
	N/A Dimensions	Visual	2 Qty

Ref	Dimensions	Visual	Qty
L6	N/A		1
Ref	Dimensions	Visual	Qty
S5	N/A		2
Ref	Dimensions	Visual	Qty
S6	N/A		1

