


next

Aubrey 7 Light 732015

Actual product size

Max/Min drop 112/60 x Diam 58cm




next

Aubrey 7 Light 732015 Assembly instructions

Actual product size

Max/Min drop 112/60 x Diam 58cm



Need Help?

With: Assembly instructions
Missing or damaged parts

CALL: 0333 777 8999

IMPORTANT — RETAIN FOR FUTURE REFERENCE

Before You Start

Warnings

For your safety, this product must be installed in accordance with local Building Regulations. If in any doubt, or where required by the law, consult a competent person who is registered with an electrical self-certification scheme.

Further information is available online or from your Local Authority.

We suggest you retain these instructions for future reference.

Light fittings should be connected to a 5 amp fused circuit.

This light fitting is suitable for indoor use only. When used with the supplied lightbulb it may be dimmed using a standard dimmer switch.

Before commencing installation, isolate the circuit to be used by removing the fuse or circuit breaker at the consumer distribution unit.

Do's

We suggest you spend a short time reading through this leaflet before you start.

When you are ready to start, make sure that you have the right tools and plenty of space.

Unwrap all packaging materials and place the components on a clean surface to protect it from damage.

Carefully check that you have all the parts before beginning assembly.

Always switch off the supply before changing lightbulbs or cleaning.

Allow bulbs to cool down before handling.


Don'ts

The fitting should not be fitted to newly painted or plastered surfaces as this may cause discolouration of the finish.

We recommend cleaning with a soft dry cloth. Do not use abrasive materials as these will rub away the protective coating.

Number of people required to assemble

One Person who is competent with electrical wiring and installation, however we do recommend that this item is installed by a qualified electrician.



Time to assemble

About 1.5 hours.

Tools required

Two screwdrivers one suitable for a slotted screw and one suitable for a cross-headed screw

Small electrical screwdriver

Insulating tape

Missing parts

If you are missing any fixtures and fittings for your product, please contact our customer service team on 0333 777 8999 and they will be happy to arrange for a replacement to be sent to you free of charge.

You can write to us at

Home Customer Services

Next Retail Ltd,


Desford Road,

Leicester,

LE19 4AT

To View our full light fitting range please visit
www.next.co.uk

GETTING TO KNOW YOUR PRODUCT



Components supplied. Please use this guide if you require replacement parts.

Pcd	Description	Spec	Qty	Remark
1	Light fitting	7 Light	1	
2	Decorative scrolls		7	Packed in tray
3	Candle drip	H63 x Dia 8.5mm	7	Packed in tray
4	3-way connection block	PA7F	1	Packed in fixing pack
5	Fixing screws	M4 x 38 PA	2	Packed in fixing pack
6	Assembly instructions	A4 x 2	1	Packed in fixing pack
7	Re-package instructions	A4 x 1	1	Packed in fixing pack
8	Crystal string "A"		28	Packed in inner box
9	Crystal string "B"		14	Packed in inner box
10	Crystal string "C"		7	Packed in inner box
11	Crystal string "D"		7	Packed in inner box
12	Crystal string "E"		1	Packed in inner box
13	Crystal string "F"		7	Packed in inner box
14	Glass sconce	H30 x Dia 100mm	7	Packed in inner box

Assembly Instructions


Step 1

This product has been supplied in knock down format and will require assembly before use.

- Attach the centre stem to the centre body, and pull surplus cable through ceiling cup. Ensure threads are correctly aligned. Hand tighten only and do not over tighten. (See Figure 1.)
- Adjust arms ensuring they are evenly spaced. Adjust by holding the lampholder and the centre body and rotating the arms to the required position.
- Remove the screws from the metal plate at the top of the centre stem and retain for later use. Locate the lower end of each decorative scroll into the corresponding hole in the centre body. Secure top and bottom of decorative scrolls by tightening screws.

Step 2

- Remove fixing bracket screws and locking washers from the fixing bracket and retain for later use. (See Figure 2.)
- To adjust the chain length remove the chain links by bending the links with a pair of pliers. When you have the preferred length of chain, link the chain to the ceiling cup.



Step 3


Dressing the fitting

Dress the fitting by referring to the diagram below, starting from the bottom of the fitting and working upwards. (See Figure 3.)

- 1) Hang droplet "E" on the ring under the centre body of the fitting.
- 2) Attach chain "F" between the ends of each lower decorative scroll.
- 3) Attach droplet "B" to the bottom of each lampholder arm.
- 4) Attach droplet "B" to the outer loop of each lampholder arm.
- 5) Attach 4pcs of droplet "A" to each glass sconce.
- 6) Place a candle drip over each lampholder then place a glass sconce over each candle drip.
- 7) Attach chain "D" between the upper ends of two adjacent middle decorative scrolls.
- 8) Attach chain "C" between the upper ends of two adjacent top decorative scrolls.

Step 4

Remove the sleeving from the ends of the connecting wires in your light fitting, cutting carefully with scissors to avoid damaging the wires. Support the weight of the fitting, then using the connector block supplied, connect the wires in the following way: (See Figure 4.)



Step 5

Check that

- ◆ you have correctly identified the house wires for the light fitting.
- ◆ connections are tight.
- ◆ no loose strands have been left out of the connection block(s).


Wrap two layers of electrical insulation tape around the connector block and around the wiring 2cm each side of the connector block.

Step 6


When all connections are insulated, offer the ceiling cup up to the fixing bracket. Align the side screws with the corresponding slots. Then tighten the side screws. (See Figure 5.)

Selecting the correct lightbulb

- ◆ Maximum Wattage – 28W ECO halogen or 4W LED
- ◆ Lightbulb shape - Candle.
- ◆ Lightbulb type – Small Edison Screw



Do not exceed the maximum wattage as this may cause your light fitting to overheat. Screw a bulb to each lampholder. (See Figure 6.)



Switch on!

You may now switch the electricity back on. We are sure you will be pleased with your new NEXT light fitting and that it will give you many years of trouble free enjoyment.

Cleaning care

We recommend cleaning with a soft dry cloth. Do not use abrasive materials as these will rub away the protective coating.

Safety information

For your safety, please remember the following:

- Always switch off the supply before changing lightbulbs or cleaning.
- Allow bulbs to cool down before handling.