

next

SOUTHPORT DOUBLE CABINET

858185

Assembly instructions

Actual product size

H58 x L63 X D16cm



IMPORTANT - RETAIN FOR FUTURE REFERENCE

Need Help?

With: Assembly instructions
Missing or damaged parts

CALL: 0333 777 8999

BEFORE YOU START

Warnings

Important: Retain these instructions for future reference.

Unwrap all packaging materials and place the components on top of the carton box or on a clean floor to prevent it from damage.

Keep fittings out of children's reach and keep children well away from construction area.

Please periodically check all fittings and re-tighten as necessary.

Avoid exposing the furniture to excessive heat or direct sunlight as this can cause cracking of the wood and deterioration of the colour.

Do's

We suggest you spend a short time reading through this leaflet before you start.

When you are ready to start, make sure that you have the right tools, plenty of space and a clean, dry area for assembly.

Carefully check that you have all the parts before beginning assembly.

During assembly children should be kept away from the product due to possible risk of injury.

Tools not included.

Ensure that this product is fully assembled as illustrated before use and all fixings are fully tightened before use .

Check all screws or bolts are tightened and inspect regularly.

To clean your item, wipe with soft cloth slightly dampened with water. Then buff with a dry clean cloth.

Unwrap all packaging materials and place the components on a clean surface to protect it from damage.

We recommend that the packaging is used to protect the surface during assembly.

Don'ts

Do not use power tools to construct this product.

Do not tighten screws until fully assembled.

Do not overtighten screws or bolts.

Do not use this product if parts are missing, damaged or worn.

Do not use silicone based furniture polish. Silicone in furniture polishes can break down the lacquer finish.

Never use scourers, abrasives or chemical cleaners.

Number of people required to assemble

Two people are required to assemble this product.

Time to assemble



1 hour


Tools required



not supplied



not supplied



not supplied

Missing parts

If you are missing any fixtures and fittings for your product please contact our customer service team on **0333 777 8999** and they will be happy to arrange for a replacement to be sent to you free of charge.

Home service technicians


If you have a fault with your product please contact our customer service team on **0333 777 8999**. If you have had the product for 28 days or less you may be offered a replacement, refund or for a fully trained home service technician to visit your home to assess the fault and repair the product where possible. If you have had the product for more than 28 days we will send an independent home service technician to review and repair the product where possible and recommend further action.

You can write to us at








Home Customer Services
Next Retail Ltd,
Desford Road,
Leicester,
LE19 4AT







To view our full furniture range please visit www.next.co.uk

GETTING TO KNOW YOUR PRODUCT




Components supplied-Use this guide if you require a replacement part.

Ref	Dimensions	Visual	Qty
1	63 x 16cm		1
2L	54.5 x 14.5cm		1
2R	54.5 x 14.5cm		1
3	63 x 16cm		1
4	56.5 x 34cm		1
5	56.5 x 25cm		1
6	54.5 x 14cm		1



Ref	Dimensions	Visual	Qty
7	23.5 x 11.5cm		2
8	32.5 x 11.5cm		2
9	57.5 x 2cm		1
10	57.5 x 2cm		1
11	50.5 x 32cm		1
12	50.5 x 23cm		1

Fixtures and fittings supplied (actual size)


Ref	Dimensions	Qty
A	6 x 35mm	6
B	15 x 9.5mm	6
C	6 x 30mm	10
D	4 x 30mm	12
E	3 x 12mm	17
F	8 x 1.5mm	2
G	3 x 12mm	16
H	6 x 18mm	16
I	4 x 16mm	2




Fixtures and fittings supplied (not to scale)

Ref	Dimensions	Visual	Qty
J	23 x 25mm		2
K	84 x 54mm		4



1



C x 2 6 x 30mm





2





D x 3 4 x 30mm




3



4




5



CAM-PILLAR


Tighten until shoulder is flush with panel. Do not overtighten or undertighten (see example below)




6 x 35mm
A x 6



6 x 30mm
C x 5




6



4 x 30mm
D x 3




7





15 x 9.5mm
B x 6

8



3 x 12mm
E x 17


9



3 x 12mm
G x 8

52 x 84mm
K x 4

10





F x 2

8 x 1.5mm




11



3 x 12mm
G x 8



12




4 x 16mm
I x 2




23 x 25mm
J x 2




13




6 x 18mm
H x 16



14




15



16

Wall fixings are not included please source suitable fixings for your wall type. If in doubt, please consult a qualified trades person. **WARNING:** Always ensure the wall to be drilled is free from hidden electrical wires, water and gas pipes.



Actual product size

H58 x L63 X D16cm

